



Aluminum Alternating Tread Stairs Assembly and Installation Instructions



Thank you for purchasing the Lapeyre stair...

With proper installation, your Lapeyre stair will give you many years of maintenance-free service.

What You'll Need:

Floor/Hammer Drill • Crescent Wrench Socket
Wrench • 3/4" socket • Mounting bolts

Handrail Clearance

When placing the stair, a minimum of 6" should be provided between the handrails and any other object (a minimum of 12" between handrails on two adjacent stairs).

Installation of the Stair

- 1 Install the stair with the top tread at the same elevation as the upper finished floor or roof surface.
- 2 Prepare the mounting holes for the stair, using the bolt patterns shown (Fig. 1 and Fig. 2) as a guide.
- 3 Put in position and securely bolt both the landing (Fig. 3) and footing (Fig. 4) of the stair. Make sure footing is secured parallel to the landing to avoid twisting. Bolts are not provided. Use bolts or studs (minimum 1/2" diameter).

